



Stern offers the following advice to help keep games clean and safe to play:

- When using a disinfectant product, do not allow it to soak into the decal. Spray and immediately wipe the surface with a clean, soft rag.
- Before using, always test your cleaning solution on a small area.
- The manufacturers of Stern's decals suggest cleaning the decals with a solution of 90% water/10% bleach.
- Certified disinfectant spray such as Lysol or Clorox wipes work best as an alternative to water/bleach solutions.
- Regularly clean the start button, flipper buttons, plunger, action button (if there is one), coin door and metal trim at the front of the game as specified in the AMOA guidelines.

We thank you for your continued efforts to ensure both a fun and healthy pinball environment.

[Cleaning and Sanitizing Guidelines from the AMOA.](#)