



Cleaning Methods for TouchTunes Jukebox Touchscreens

This document describes the recommended cleaning and disinfecting procedure for TouchTunes Jukebox screens. Included are recommended disinfectant products that are safe for use with TouchTunes Jukebox screen and approved by the US Center for Disease Control and Prevention (CDC) and the US Environmental Protection Agency (EPA).

Cleaning your TouchTunes Jukebox screen

1. Do not spray the screen directly. Instead, use wet wipes, a sprayed cloth or a dampened cloth with the excess moisture squeezed off.
2. Select only non-abrasive cleaning wipes or cloths to avoid scratching touchscreens.
3. Avoid highly concentrated alcohol (> 70%), non-diluted bleach or ammonia solutions, as these may cause discoloration.
4. Wipe the surfaces with the appropriate wipes or cloths and approved cleaning products, and allow them to dry.

Disinfecting your TouchTunes Jukebox screen

1. Dampen a new clean, non-abrasive cloth with a disinfectant chosen from the list below. Ensure excess liquid is squeezed from the cloth. You may also use recommended pre-dampened wipes
2. Read the manufacturer's instructions carefully. Many manufacturers require the surface to remain wet for a few minutes, so continuous wiping might be required.
3. Disinfect the surfaces by wiping them with the cloth or wipe, and allow the surface to dry.
4. For disinfectant solutions that are safe for use with TouchTunes jukebox screens, see below.

Source: Elo Touch Solutions, Inc.

US CDC-recommended disinfectant solutions safe for TouchTunes Jukebox screens

- Household bleach solution (1/3 cup of bleach per gal. of water)
- Isopropyl alcohol (\leq 70% alcohol)

More information from the CDC on disinfecting procedures for Coronavirus Disease 2019 (COVID-19) can be found here: <https://www.cdc.gov/coronavirus/2019-ncov/community/home/cleaning-disinfection.html>

US EPA-recommended disinfectants safe for TouchTunes Jukebox screens

- | | |
|--|--------------------------|
| • Clorox® Disinfecting Wipes | Reg. No. <u>5813-79</u> |
| • Clorox® Healthcare Bleach Germicidal Wipes | Reg. No. <u>67619-12</u> |
| • Clorox® Commercial Solutions Hydrogen Peroxide Cleaner Disinfectant Wipes | Reg. No. <u>67619-25</u> |
| • Lonza® Disinfectant Wipes | Reg. No. <u>6836-313</u> |
| • Lysol® Brand Clean & Fresh Multi Surface Cleaner (20% cleaner solution to water ratio) | Reg. No. <u>777-89</u> |
| • Purell® Professional Surface Disinfectant Wipes | Reg. No. <u>84150-1</u> |
| • Sani-Cloth® Prime Germicidal Disposable Wipes | Reg. No. <u>9480-12</u> |

More information from the EPA on recommended disinfectants for Coronavirus Disease 2019 (COVID-19) can be found here: <https://www.epa.gov/pesticide-registration/list-n-disinfectants-use-against-sars-cov-2>

Do NOT use the following materials when cleaning/ disinfecting your TouchTunes jukebox screens



- | | |
|--|---|
| • Isopropyl Alcohol at concentration > 70% | • Detergents with ammonia at concentration > 1.6% |
| • Methyl Alcohol or Ethyl Alcohol at concentration > 35% | • Detergents with abrasives |
| • Thinner or benzine | • Formula 409 |
| • Strong alkali lye | • Steel wool |
| • Strong solvents | • Sponges with abrasives |
| • Acids | • Steel blades |
| • Detergents with fluoride | • Cloth with steel threads |
| • Abrasive cleaners | |

Source: Elo Touch Solutions, Inc.